



Arctic Cat / Wildcat Trail / Slip-On / Titan Series

For Models: Wildcat Trail (2014-2017), Wildcat Sport (2015-2015)

Removal

- 1) Use a long piece of electrical wire to remove the springs from the silencer to head pipe joint.
- 2) Pull back on the silencer to remove it.

Installation

- 1) Inspect the gasket at the end of the **head pipe** for wear or damage. Replace it if necessary.
- 2) Position your new silencer in the stock location. The Titan Series uses round bar hangers that slide through the rubber grommets on the frame.
- 3) Use a long piece of electrical wire to install the supplied springs at the head pipe to the silencer joint. *(See Figure #1)*
- 4) Check all areas around the exhaust for proper alignment and clearance. Adjust if necessary.

Hardware



(2) 400078 - Spring(s) - Short

* Click thumbnails to enlarge

Figure #1



(2) Spring(s) - Short

